

Boeing 727 Series Aeroplanes

---

**AD/B727/48**

**Stabilizer Trim System Brake  
Assembly - Modification**

**5/67**

Applicability: All models.

Requirement: Install additional spacers under pawls in the stabilizer trim system brake, Boeing P/N 10-60822-1, Western Gear P/N 4472, R155, Western Gear S/Nos. 101 through 225, in accordance with para. 2 of Western Gear SB "Flight Controls - Stabilizer Brake Assembly, Western Gear P/No. 4472 R155 Install Additional Spacers Under Pawls".