COMMONWEALTH OF AUSTRALIA CIVIL AVIATION SAFETY AUTHORITY SCHEDULE OF AIRWORTHINESS DIRECTIVES

Grumman G21 (Goose) Series Aeroplanes

AD/G21/1

Below Floor Control System Components - Inspection

10/77

Applicability: All models.

Requirement: 1. Remove and disassemble:

- (i) Elevator Torque Tube Assembly P/N 12755,
- (ii) Rudder Torque Tube Assembly P/N 12756,
- (iii) Rudder Pedal Torque Tube Assembly LH and RH P/N 12757 and 12758,
- (iv) Hinge Support Assembly P/N 12725.
- 2. Inspect all parts for corrosion and/or cracks using visual and dye penetrant or magnetic particle techniques.

Note: FAA AD 73-12-6 Amendment 39-1657 refers.

Compliance:

Initially before issue of Certificate of Airworthiness and there- after at intervals not exceeding 2000 hours time in service or two years whichever occurs first.