

Aerospatiale Rallye Series Aeroplanes

AD/MSR/22

Rear Fuselage Structure - Inspection

6/76

Applicability: All models.

Requirement:

1. Remove the fuselage tail-cone and fin dorsal fairing and, with the aid of a torch, visually inspect the fuselage internal and external stringers for corrosion.
2. If corrosion is detected remove the empennage components and perform a detailed visual inspection of the rear fuselage structure for corrosion damage.

Compliance: Before 15 July 1976 and thereafter at intervals not exceeding 3 years.