

Transavia PL 12 Series Aeroplanes

**AD/PL 12/11
Amdt 1**

**Nose Wheel Pivot Pin - Inspection
and Replacement**

5/75

Applicability: All models with S/Nos. prior to G576 not incorporating SB No. 27.

Requirement: 1. Check nosewheel pivot pin P/N 6-24 for correct torque in accordance with Transavia PL-12 Maintenance Manual.

2. Replace nose wheel pivot pin if torque is found incorrect.

3. Remove pivot pin and inspect for wear, cracks and signs of abnormal loading.

Compliance: For Para. 1 - Within 10 hours time in service after 10 September 1973.

For Para. 2 - Before further flight.

For Para. 3 - At next inspection for issue of maintenance release completed after 10 September 1973 and thereafter at intervals not exceeding 100 hours time in service.