

Piper PA-44 (Seminole) Series Aeroplanes

AD/PA-44/9 **Aileron Balance Weight Attachment** **10/81**
Inspection and Modification

Applicability: All models PA-44-180 with serial numbers 44-7995001 to 44-8195016. All models PA-44-180T with serial numbers 44-8107001 to 44-8107044.

Document: Piper S.B. No. 725A. FAA AD 81-16-10 refers.

Compliance: Part I: Initially inspect before further flight and thereafter at intervals not exceeding 25 hours time in service until modified in accordance with Piper S.B. No. 725A.

Note: The pilot in command may perform and certify for this inspection.

Part II: Within 200 hours time in service after 21 August 1981.

Background: It is possible that the aileron balance weights may become loose in the outboard leading edge of the aileron.